

## PERIODIC MAINTENANCE CHART

Item	miles	15 000	19 000	22 500	26 000	30 000
	months		6	12	18	24
<b>Air cleaner</b> (K&N clean at 60000)			I	I	I	I
<b>Spark plugs</b>		R	I	R	I	R
<b>Tappet clearance</b>		I	-	-	-	I
<b>Engine oil</b>		R	R	R	R	R
<b>Engine oil filter</b>		-	R	-	R	-
<b>Fuel hose</b>		I	I	I	I	I
		Replace every 4 years.				
<b>Engine idle speed</b>		I	I	I	I	I
<b>Carburetor synchronization</b>		I	-	I	-	I
<b>Throttle cable play</b>		I	I	I	I	I
<b>Clutch cable play</b>		I	I	I	I	I
<b>Radiator hoses</b>		I	I	I	I	I
<b>Engine coolant</b>		Replace every 2 years				
<b>Drive chain</b>		I	I	I	I	I
		Clean and lubricate every 600 miles				
<b>Brakes</b>		I	I	I	I	I
<b>Brake hoses</b>		I	I	I	I	I
		Replace every 4 years.				
<b>Brake fluid</b>		I	I	I	I	I
		Replace every 2 years.				
<b>Tire</b>		I	I	I	I	I
<b>Steering</b>		I	-	I	-	I
<b>Front forks</b>		I	-	I	-	I
<b>Rear suspension</b>		I	-	I	-	I
<b>Exhaust pipe bolt and nut</b>		T	-	T	-	T
<b>Chassis bolt and nuts</b>		T	T	T	T	T

*I = Inspect and adjust, clean, lubricate or replace as necessary:*

*R = Replace*

*T = Tighten*